



Smoke Alarm Controller

CODE: QFS-EL-CTR

Accessory

Elite Series



Features

- Remote smoke alarm tester
- Test for low battery
- Locate fire in property
- Stop alarm from sounding with silent button

Specification	QFS-EL-CTR
Power	CR2450 replaceable battery
Battery Lifetime	3 years
Frequency	433MHz
Modulation	FSK
Operating Temperature	0 to +40°C
Operating Humidity	15% to 95% (non-condensing)
RF Performance	AS4268
EMC Performance	EN 301 489-1, EN 301 489-3



Smoke Alarm Controller

CODE: QFS-EL-CTR

Accessory

Elite Series

Functions

Test	Press the "TEST" button once. All interlinked smoke alarms will beep for 7 seconds	 7
Locate	Pressing "LOCATE" button once. All interlinked alarms will be silent apart from the alarm detecting smoke	 
Silence	Press the "SILENCE" button once. All interlinked smoke alarms will be silent for 8 minutes	 × 8min
Fire Indicator	The indicator will flash 2x per second if an alarm detects smoke	  0.5
Low Battery	The yellow LED will flash once every 8 seconds	  8

